



Navitas Advanced Access

The Navitas Vehicle Systems app is available for download in the [Google Play Store](#), or the [Apple App Store](#).
(Search “Navitas Vehicle Systems Ltd.)

Advanced app features are also available in the app after accepting and completing liability terms & conditions form.
(Advanced app access is a privilege provided by NVS, is available at the discretion of NVS.)




1. Once installed, open the app and either connect to your controller or open the dashboard in either the TSX or TAC demo mode.

OR


Pull down to refresh list below	
Controller Name	Signal
TAC_0498900019	-71dBm
TAC_0483000097 (Secured to this phone)	-72dBm
TSX_0455000359	-90dBm

2. In the top left hand menu ☰, go to the login screen






3. Click "Sign Up" beneath the LOGIN button




NAVITAS

4. Fill out the fields in the form to create a username and password for your account. Once finished, a verification email will be emailed to you. You will need to click the link in the email after signing up, so be prepared once you click sign up




NAVITAS


5. Once you have verified your email with Navitas, return to the app, click continue and the app will bring you back to the dashboard screen.



6. Tap the settings menu at the bottom




7. In the settings menu, click the "Request Advanced Access" button





8. Submit the form. Navitas will review and approve your application. The advanced functions will now be available in your settings menu.



Privacy Statement:
User information required for warranty/service/security.



9. Your request will be verified. Once approved you will have advanced access.
Advanced Access is subject to validation by Navitas Vehicle Systems Ltd.

